

Installation tips...

A small amount of dish detergent mixed with water in a spray bottle helps in positioning the pins when you're putting the tiles together. Just spray a light mist on the joints, line up the pins over the receiving holes, and press them together. A light tap with a rubber mallet can be used if they're still stubborn in going in. We recommend hosing the entire mat down with water to remove any soap residue before you install the assembled mat in your sauna, around your pool, or general floor area. The entire assembled mat should easily roll up in one piece for removal. This allows the floor to be cleaned at any time with a minimum of effort.

Cutting tiles to size...

The tiles are easily cut to accommodate any corner or wall. We recommend you cut the underside grid that runs perpendicular to the top grid. This will result in a neat appearance when you're finished installing the tiles.

Edges...

The color-matching edges are recommended anywhere you want a nicely contoured bevel at the edge of the floor tiles. The 45 degree flange on the corner can be cut off straight, if you want a series of edges joining in a row. We also sell edges in "safety yellow" to clearly identify your mat area, ideal for public installations.

Features:

- U.V. stable material with fungus inhibitors; mould and mildew proof.
- provides superior traction in wet and dry environments.
- conforms to irregular floor levels, "cushion" surface.
- easily removed in one piece to permit floor cleaning.
- snap together interlocking connections.
- a "ramped" edge supports wheelchairs and rolling stock.
- superior to hard plastic traditional tiles.
- usable to -35 degrees Celsius.